

ExtraBolt 4.5

Installation:

- 1)** Put medium threadlock (loctite 243) on bolt thread only.
- 2)** Install ExtraBolt4.5 and tight to 7-8Nm.

WARNING: overtightening can seriously compromise brake assembly safety.

Studio Riva S.R.L. Tel. ++39-0371-203059
info@extralite.com

EXTRALITE