



**CONTENTS:**

- > Easy Bleed Kit Funnel – HTT0013 (Fig\_001)
- > Easy Bleed Kit Plunger – HTT0014 (Fig\_001)
- > Easy Bleed Kit Lid (Fig\_002)  
(different models sold separately) and its seal  
HTT0010 – Race/Race EVO  
HTT0011 – Tech 3  
HTT0012 – Tech/Tech EVO
- > Bleed Nipple Adapter – HTTBNA-S
- > 0.5m Clear Pipe
- > Optional : 250mL bottle of DOT 5.1 brake fluid



Fig\_001



Fig\_002

**PREPARATION OF BLEEDING OPERATION :**

- 001\_ Wrap a tissue or rag around the master cylinder in case of any unfortunate spillage.
- 002\_ Remove existing lid and take off diaphragm.
- 003\_ Place the cut out diaphragm and screw on easy bleed kit lid.
- 004\_ On the M5 port hole of the bleed lid, screw on the easy bleed kit funnel with the plug installed in.
- 005\_ Fill the funnel with DOT5.1 brake fluid from a clean tub (DOT4 is also acceptable)
- 006\_ On the caliper end, place the nipple fitting on the end of the bleed nipple.
- 007\_ Place the waste pipe in a waste bottle or jar.

- 004\_ Remove the funnel with the plug still in place.
- 005\_ Unscrew the bleed kit lid and diaphragm.
- 006\_ On the caliper end, push the pistons fully back in their housing.
- 007\_ If the master cylinder reservoir isn't totally full, top it up with brake fluid.
- 008\_ Replace the rubber diaphragm. (the one which is not cut out!)
- 009\_ Re install the master cylinder lid and screw it in place, slightly nip the M3 screws, do not overtighten them.
- 010\_ Clean any spillage.
- 011\_ You can let any extra brake fluid from the funnel drain back into the brake fluid bottle.

**BLEEDING PROCEDURE :**

- 001\_ Remove the easy bleed kit plug so the fluid can migrate into the mcyl reservoir
- 002\_ Pull the brake lever until you can feel it resisting or it goes against the bars
- 003\_ Whilst maintaining the brake lever pulled, open the bleed nipple (a quarter of a turn is normally enough) – you should observe some fluid or air coming out into the waste pipe
- 004\_ Close the bleed nipple and let the lever go – in the funnel the fluid level should be going down
- 005\_ Repeat step 2 to 4 several times until the brake fluid coming out the waste pipe is clean and the lever feels solid when pulling it. Although the funnel should contain a sufficient amount of brake fluid for the bleeding operation, make sure the level doesn't go below the last quarter.

**FINISHING OFF THE BLEEDING OPERATION :**

- 001\_ When you are satisfied with how the lever feels, re-install the easy bleed kit plug.
- 002\_ Close properly the bleed nipple but do not overtighten it.
- 003\_ Remove the nipple fitting and waste pipe.

**USEFUL TIPS AND TRICKS, GENERAL INFO :**

- 001\_ It is highly recommended you use latex gloves and protective glasses when doing the bleeding procedure.
- 002\_ Again, when doing the bleeding procedure, make sure there is always some brake fluid in the funnel.
- 003\_ If initially there is no brake fluid in your brake system, you want only to perform brake fluid replacement, or the lever goes constantly to the bar you can open the bleed nipple and without touching the brake lever let the fluid drain down by gravity. You should see the fluid level going down in the funnel. If not follow the procedure as normal.
- 004\_ Make sure the bleed nipple is pointing upwards and that no air can be trapped in the caliper body. Especially on the rear, it is sometimes useful to take the caliper off the frame/forks mount depending on its position.
- 005\_ If left on painted surfaces, brake fluid can be corrosive, wipe out any spillage.
- 006\_ Dispose old brake fluid in a recycling centre, be responsible. Do not pour it down the drain under any circumstances, it can damage the environment and waste pipe.

**HOPE TECHNOLOGY (IPCO) LIMITED**

Hope Mill, Calf Hall Road, Barnoldswick, Lancashire, BB18 5PX, United Kingdom

T: 01282 851400 F: 01282 851201 E: info@hopetech.com

**HOPETECH.COM** // f @ t v